




2018 **LEAF**<sup>®</sup>

QUICK REFERENCE GUIDE





- |   |   |  |   |
|---|---|--|---|
| <b>1</b> Vehicle Information Display*/<br>Power Meter/Li-ion Battery<br>Temperature Gauge | <b>6</b> Charge Port Lid Switch   | <b>13</b> Cruise Control/Bluetooth®/<br>ProPILOT Assist Switches | <b>19</b> USB Port/AUX Jack/<br>iPod® Interface |
| <b>2</b> Li-ion Battery Available Charge<br>Gauge/Driving Range                           | <b>7</b> Immediate Charge Switch*   | <b>14</b> Wiper and Washer Switch                                | <b>20</b> Front Heated Seat Switches            |
| <b>3</b> Headlight, Fog Light and<br>Turn Signal Switch                                   | <b>8</b> Heated Steering Wheel Switch*  | <b>15</b> Control Panel Touch<br>Screen Display                  | <b>21</b> 12-Volt Power Outlet*                 |
| <b>4</b> Instrument Brightness<br>Control Switch*   | <b>9</b> Steering Assist Switch   | <b>16</b> Heater and Air Conditioner<br>(automatic)              | <b>22</b> Shift Lever                           |
| <b>5</b> Twin Trip Odometer Switch*   | <b>10</b> Hood Release*   | <b>17</b> Front Passenger Air Bag<br>Status Light*               | <b>23</b> e-Pedal Switch                        |
|   | <b>11</b> Tilting Steering Wheel Lever*   | <b>18</b> Push-Button Power Switch                               | <b>24</b> ECO Switch                            |
|   | <b>12</b> Steering Wheel Switches<br>for Audio Control/Navigation/<br>Vehicle Information Display |  |   |

\*See your Owner's Manual for information.

# TABLE OF CONTENTS

## NEW SYSTEM FEATURES

How to Use Your LEAF's Touch-Screen Display (if so equipped)	3
NissanConnect® EV & Services Powered by SiriusXM® (if so equipped)	4
ProPILOT Assist (if so equipped)	6
e-Pedal System	9
Intelligent Around View Monitor (if so equipped)	10
Intelligent Driver Alertness (I-DA) (if so equipped)	11
Automatic Emergency Braking (AEB) (if so equipped)	12
Automatic Emergency Braking (AEB) with Pedestrian Detection System (if so equipped)	12
Lane Departure Warning (LDW) and Intelligent Lane Intervention (I-LI) (if so equipped)	13
Blind Spot Warning (BSW) with Rear Cross Traffic Alert (RCTA) (if so equipped)	13
Approaching Vehicle Sound for Pedestrians (VSP) System	14
Heated Seats (if so equipped)	14
SiriusXM Travel Link and SiriusXM Traffic (if so equipped)	14
Shift Control System	15
Apple Carplay™ (if so equipped)	16
Android Auto™ (if so equipped)	17

## ESSENTIAL INFORMATION

Cold Weather Range and Parking in Extremely Cold Weather	19
Quick Charge in Cold Weather (if so equipped)	19
Li-ion Battery Temperature Gauge and Li-ion Battery Gauges	20
Power Limitation Indicator Light	20
Charge Port Lid/Charge Connector Lock System	21
Li-ion Battery Charging	22
Tire Pressure Monitoring System (TPMS) with Easy-Fill Tire Alert	24
Clock Set/Adjustment	25

## FIRST DRIVE FEATURES

Nissan Intelligent Key® System	26
Outside Mirror Control Switch	26
Front Power Seat Adjustments (if so equipped for driver's seat)	27
Rear Hatch Release	27



Additional information about your vehicle is also available in your Owner's Manual, NissanConnect® Manual (for Leaf) and at [www.NissanUSA.com](http://www.NissanUSA.com).



Please see your Owner's Manual for important safety information and system operation limitations.

- A cellular telephone should not be used for any purpose while driving so full attention may be given to vehicle operation.
- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the "Safety — Seats, seat belts and supplemental restraint system (section 1)", the "Monitor, climate, audio, phone and voice recognition systems (section 4)" and the "Starting and driving (section 5)" of your Owner's Manual and your NissanConnect® Manual (for Leaf).

# TABLE OF CONTENTS

## FIRST DRIVE FEATURES

Power Meter .....	28
Electric Vehicle (EV) System Warning Light .....	28
Starting/Stopping the Electric Vehicle (EV) System .....	28
Headlight Control Switch .....	29
Wiper and Washer Switch .....	30
Heater and Air Conditioner (automatic) .....	31
FM/AM/SiriusXM® Satellite Radio with CD Player (if so equipped).....	33
USB (Universal Serial Bus) Connection Port/AUX Jack and iPod® Interface .....	35
Cruise Control (if so equipped).....	35
Intelligent Cruise Control (ICC) (if so equipped) (for vehicles without ProPILOT Assist) .....	36

## SYSTEM GUIDE

Vehicle Information Display.....	37
Bluetooth® Hands-free Phone System .....	38
System Operating Tips.....	38
Bluetooth® System without Navigation (if so equipped) .....	38
Bluetooth® System with Navigation (if so equipped) .....	40
Hands-free Text Messaging Assistant .....	42
Bluetooth® Streaming Audio.....	43
Navigation System (if so equipped).....	44
HomeLink® Universal Transceiver (if so equipped).....	46



Additional information about your vehicle is also available in your Owner's Manual, NissanConnect® Manual (for Leaf) and at [www.NissanUSA.com](http://www.NissanUSA.com).



Please see your Owner's Manual for important safety information and system operation limitations.

- A cellular telephone should not be used for any purpose while driving so full attention may be given to vehicle operation.
- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the "Safety — Seats, seat belts and supplemental restraint system (section 1)", the "Monitor, climate, audio, phone and voice recognition systems (section 4)" and the "Starting and driving (section 5)" of your Owner's Manual and your NissanConnect® Manual (for Leaf).

# NEW SYSTEM FEATURES



## HOW TO USE YOUR LEAF'S TOUCH-SCREEN DISPLAY (if so equipped)

- 1** Launch Bar - Various functions can be accessed by touching the items on the Launch Bar **1**, which is displayed on most of the main screens. Touching these keys will bring up the corresponding screens.
- 2** Widget - These items can be interchanged, moved, or deleted from the MENU pages.
- 3** Touch either arrow to navigate to the next or previous page of the "MENU" screen. These screens can also be swiped, as you would with a smartphone, to move from screen to screen.
- 4** These dots indicate the page you are currently on, in white, out of the number of pages there are available, in gray.
- 5** Shortcut - Shortcuts, once touched, will bring up the system they correspond to for quick, one-touch convenience for commonly used features.
- Shortcuts and Widgets can be set up through the "Edit Menu" screen which can be accessed by touching the "Settings" key **6** followed by the "Edit Home Menu" key **7**. This will display the "Edit Menu" screen, which allows Shortcuts and Widgets to be moved and rearranged **8**, deleted **9** and created **10**.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to your NissanConnect® Manual (for Leaf).

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

# NEW SYSTEM FEATURES

## NISSANCONNECT® EV & SERVICES POWERED by SiriusXM® (if so equipped)

NissanConnect® EV & Services is a collection of telematics features that add innovation to your daily drive.


NissanConnect EV enables you to perform remote functions from a compatible internet-enabled smartphone or personal computer such as:

- Battery status check, the status of the battery can be checked even if you are not in the vehicle.
- Unplugged status and charge status, a notification e-mail can be sent if the charging connector is disconnected or if charging is complete.
- Remote charge and remote climate control, start battery charging, or climate controls can be set.
- POIs powered by Google™, allows you to search for locations near your vehicle's current location, near a plotted destination, near the map's scroll position or near a searched city center.

To enroll in NissanConnect EV & Services, create an account or log into your Nissan Owner Portal with your Vehicle Identification Number (VIN). Follow the prompts to enroll in NissanConnect Services. Next, download the NissanConnect EV & Services companion app and log into it using your Nissan Owner Portal ID and password.

For full details on NissanConnect EV & Services or to enroll your vehicle, please visit [www.NissanUSA.com/connect](http://www.NissanUSA.com/connect) or call 855-426-6628.

Here is a quick overview of some of the features that may be available for your vehicle. A full description of these and other NissanConnect EV & Services can be found in your NissanConnect® Manual (for Leaf).

- Automatic Collision Notification, a service that generates an automatic connection between the vehicle and the Emergency Response Center when the vehicle has been involved in an accident that was severe enough to deploy the air bags.
- Emergency Call, which connects you to a NissanConnect EV & Services Specialist who will assist in the dispatch of emergency services to the vehicle's location. To use this feature, press the **SOS** button **1** on the overhead console. The **SOS** button **1** should only be used in emergency situations.
- Roadside Assistance, which dispatches roadside assistance to the vehicle's location in non-emergency situations. Roadside Assistance can be accessed by touching the  headset icon **2** on the map screen, via NissanConnect EV & Services Companion app or by calling the Roadside Assistance provider directly.




To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

- **Stolen Vehicle Locator**, a service that works in coordination with law enforcement agencies to assist in the recovery of a stolen vehicle.
- **Remote Door Lock/Unlock**, for use when you forget to lock your car or if you need to open it and don't have the keys. To use this feature, log into the NissanConnect EV & Services companion app or website or contact a NissanConnect EV & Services Response Specialist.
- **Alarm Notification**, this system will notify you when the factory-installed vehicle alarm system has been activated.
- **Maintenance Alert**, review notifications via a selected method of a vehicle system malfunction that triggers instrument panel warning lights.
- **Connected Search**, select "Connected Search" from the Destination menu on the vehicle's Navigation System to conduct a Point of Interest (POI) search within a certain distance of the vehicle's location.
- **Valet Alert**, use Valet Alert to set up a 0.2-mile radius around your vehicle. Activate alerts via the NissanConnect EV & Services companion app or website.
- **Curfew Alert**, specify curfew limits via the NissanConnect EV & Services companion app or website and will be notified via a selected method if curfew is violated.
- **Journey Planner**, a feature that allows you to send a route with a destination and up to five way points directly to the vehicle.
- **Boundary Alert**, a feature that allows you to monitor the movement of your vehicle in and out of specified regions you have set on the Monitoring section of the NissanConnect EV & Services web portal or companion app.
- **Speed Alert**, which sends you alerts when your vehicle speed exceeds a threshold you have set on the web portal or companion app.

To access these features in your vehicle:

- Press the **MENU** button **3** on the control panel.
- Touch the "Info" key
- Touch the "NissanConnect EV & Services" key **4**.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "**Charging (section CH)**" of your Owner's Manual and the "**System overview (section IT)**" and your NissanConnect® Manual (for Leaf).

# NEW SYSTEM FEATURES



## PROPILOT ASSIST (if so equipped)

ProPILOT Assist is a combination of Intelligent Cruise Control (ICC) and Steering Assist. The ProPILOT Assist system is intended to enhance the operation of the vehicle when following a vehicle traveling in the same lane and direction. The ProPILOT Assist system is a “hands-on” driver assistance system and is intended for use on expressways/highways.

The driver must be prepared to steer and brake the vehicle at all times.


### SETTING THE PROPILOT ASSIST SYSTEM

1. To set ProPILOT Assist, push the ProPILOT Assist switch **1** on the steering wheel. The ProPILOT Assist system display will appear on the vehicle information display.
2. Push the **SET-** switch **4** when at the desired speed.
3. Push the distance switch **5** to select the following distance.



### PROPILOT ASSIST SYSTEM DISPLAY AND INDICATORS

- 6** Set vehicle speed indicator
  - Displays the speed set by the driver.
- 7** Steering Assist indicator
  - Shows whether Steering Assist is active or not (green-active, grey-standby, orange-malfunction).
- 8** Lane marker indicator
  - Indicates whether the system detects the lane markers.
- 9** ProPILOT Assist status indicator
  - Indicates the status of the ProPILOT Assist system by the color of the indicator (blue-active, white-standby).
- 10** Vehicle ahead detection indicator
  - Appears on the display when a vehicle is detected ahead.



To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).



## 11 Set distance indicator

- Displays the selected distance set by driver.

### CANCELLING THE PROPILOT ASSIST SYSTEM

- To cancel ProPILOT Assist, do one of the following:
  - Push the **CANCEL** switch **3** on the steering wheel.
  - Tap the brake pedal.
  - Push the ProPILOT Assist switch **1**.

### PROPILOT ASSIST INTELLIGENT CRUISE CONTROL (ICC)

- The set speed range is between approximately 20 and 90 mph (32 and 144 km/h).
- To accelerate or decelerate your vehicle to the desired speed, push the **RES+** switch **2** or **SET-** switch **4** and release it.
- When a vehicle is detected in the lane ahead, the ICC system controls the vehicle speed to maintain the distance from the vehicle ahead set by the driver.
- For more information, refer to the ICC section in this book.

### VEHICLE AHEAD DECELERATES AND/OR STOPS

- When the vehicle ahead decelerates, your vehicle decelerates to maintain the distance from the vehicle ahead set by the driver.
- Once the vehicle ahead stops, the ICC system will stop your vehicle and apply the brakes to keep the vehicle stopped.
- When the vehicle ahead accelerates, push and release the **RES+** switch **2** or depress the accelerator pedal. The ICC system starts to follow the vehicle ahead.
- If your vehicle comes closer to the vehicle ahead due to rapid deceleration of that vehicle or if another vehicle cuts in, the system warns the driver with a chime and ICC system display. The driver must control the vehicle to prevent a collision.

### STEERING ASSIST

- The Steering Assist system assists the driving operation to help keep the vehicle within the traveling lane.
  - Lane markers must be clear and consistent on both sides of the vehicle.
  - This feature will operate when vehicle speed is above 37 mph (60 km/h).
  - Below 37 mph (60 km/h), ProPILOT Assist must detect a vehicle ahead in order for steering assistance to activate.
- Steering Assist provides a warning, is canceled or temporarily goes into standby mode under the following conditions:
  - The turn signals are activated.
  - Both hands are not detected on the steering wheel. Simply apply more pressure or a tighter grip on the steering wheel.
  - The wipers are in LO or HI speed position.
  - Steering Assist will not activate if the system does not detect lane markers.

# NEW SYSTEM FEATURES

To cancel Steering Assist on Instrument Panel and Display:

- Push the Steering Assist switch **12** on the instrument panel to switch off.
- In the vehicle information display, do the following to cancel Steering Assist:
  - Use the arrow buttons **15** on the steering wheel to select "Driver Assistance". Press the **OK** button **14**.
  - Select "Steering Assist" **13**. Press the **OK** button **14**.



- Steering Assist may not operate as expected under all conditions. Always be prepared to steer if needed. For example, lighting conditions, weather, lane splits (such as exit ramps) and confusing lane markers may cause the system to not operate as expected. For more information see Owner's Manual.
- ICC may not operate as expected under all conditions. Always be prepared to brake if needed. For example, vehicles cutting into your lane or approaching stopped traffic may not be detected. For more information see Owner's Manual.



- If the driver lightly touches (instead of firmly grips) the steering wheel, the steering torque sensor may not detect the driver's hand(s) on the wheel and a sequence of warnings may occur. When the driver holds and operates the steering wheel again, the warnings turn off.

ELECTRONIC PARKING BRAKE (if so equipped)

- To apply the parking brake, pull the electronic parking brake switch **16**, located in the center console. The indicator light **17** will illuminate.
- To release the parking brake, and with the ignition switch in the ON position, depress the brake pedal and push the parking brake switch **16** down. The indicator light **17** will turn off.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instrument and controls (section 2)", "Starting and driving (section 5)", and the "Technical and consumer information (section 9)" of your Owner's Manual.

## e-PEDAL SYSTEM

- The e-Pedal system enables the driver to slow or stop the vehicle, or to keep the vehicle stopped, by operating only the accelerator pedal.
- When the e-Pedal system is activated, the regenerative brake is enhanced and the driver can adjust the vehicle speed by only depressing or returning the accelerator pedal.
- Be sure to confirm the status of the e-Pedal system in the vehicle information display before driving.
- To activate or deactivate the e-Pedal system, place the power switch in the **ON** position and pull the e-Pedal switch **1** located on the center console.
- The e-Pedal system indicator illuminates **e-Pedal 2** in the vehicle information display when the e-Pedal system has been activated. **e-Pedal OFF** illuminates when the system is deactivated.
- To turn the e-Pedal system off while the vehicle is kept stopped by the e-Pedal system, depress the brake pedal and then pull the e-Pedal switch **1**.
- The e-Pedal system will not function under the following conditions.
  - When the vehicle is placed in the **P** (Park) or **N** (Neutral) position.
  - When the cruise control (if so equipped), ProPILOT Assist (if so equipped) or Automatic Emergency Braking (AEB) (if so equipped) is operated.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "**Starting and driving (section 5)**" of your Owner's Manual.

# NEW SYSTEM FEATURES

## INTELLIGENT AROUND VIEW MONITOR (if so equipped)

- With the power switch in the ON position, the Intelligent Around View Monitor is activated by pressing the **CAMERA** button **1**, located on the navigation unit, or by moving the shift lever to the **R** (Reverse) position. The monitor displays various views of the position of the vehicle.



- When the vehicle is in the **P** (Park), **N** (Neutral) or **D** (Drive) position and the **CAMERA** button **1** is pressed, the following views will display in order:

Start from any Control Panel screen



Press




Front view & bird's-eye view



Front view & front-side view

Press



Press



- When the vehicle is in the **R** (Reverse) position and the **CAMERA** button **1** is pressed, the following views will display in order:

Rear view & bird's-eye view



Press



Rear view & front-side view



Rear-wide view

Press



Press



- The colored guide lines on the display screen indicate vehicle width and approximate distances to objects with reference to the vehicle body line.

- Red 1.5 ft (0.5 m)
- Yellow 3 ft (1 m)
- Green 7 ft (2 m)
- Green 10 ft (3 m) (if so equipped)


- For information regarding how to access additional viewing cycles, please see your Owner's Manual.

- There are some areas where the system will not show objects.

- When in the front or the rear view display, an object below the bumper or on the ground may not be viewed **2**.
- When in the bird's-eye view, a tall object near the seam of the camera detecting areas **3** will not appear in the monitor.


To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

- The distance between objects viewed on the Intelligent Around View Monitor differs from the actual distance.
- Objects in the bird's-eye view will appear farther than the actual distance.



#### MOVING OBJECT DETECTION (MOD) (if so equipped)

- The MOD system helps inform the driver of moving objects around the vehicle.
- The system will operate when the shift lever is in the **P** (Park), **R** (Reverse), **N** (Neutral) or **D** (Drive) position and the vehicle is driven at speeds of approximately 6 mph (10 km/h) or less.
- If the MOD system detects moving objects, a yellow frame will be displayed on the camera image and a chime will sound.
- When the following is displayed:
  - Blue **MOD** icon **4**; the system is active.
  - Gray **MOD** icon; the system is not active.
  - No **MOD** icon; the system is off. The indicator will also be off if all of the warning systems are deactivated using the Settings menu.
- The MOD system will not operate if the rear hatch is open.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" and "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual.

## INTELLIGENT DRIVER ALERTNESS (I-DA) (if so equipped)

- When the Intelligent Driver Alertness display is selected in the vehicle information display **1**, the system uses an audible and visual warning to suggest that the driver take a break:
  - If the system detects that driver attention is decreasing, the **Take a Break?** message **2** appears in the vehicle information display **1** and a chime sounds when the vehicle is driven at speeds above 37 mph (60 km/h).
  - If the Intelligent Driver Attention Alertness system malfunctions, the system warning message **3** will appear and the function will be stopped automatically.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)", "Monitor, climate, audio, phone and voice recognition systems (section 4)" and the "Starting and driving (section 5)" of your Owner's Manual.

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

# NEW SYSTEM FEATURES

## AUTOMATIC EMERGENCY BRAKING (AEB) (if so equipped)

- The AEB system can assist the driver when there is a risk of a forward collision with a vehicle ahead in the traveling lane.
- The AEB system will function when your vehicle is driven at speeds above approximately 3 mph (5 km/h).
- If there is a risk of a forward collision with a vehicle, an audible tone will sound and the vehicle ahead detection indicator **1** will illuminate. In addition, the system applies partial braking. If the driver does not take action, the AEB system will provide a second set of audible and visual warnings to the driver and then automatically apply harder braking.
- If there is a risk of a forward collision with a vehicle, an audible tone will sound and the AEB emergency warning indicator **2** will flash. Partial braking will be applied, followed by harder braking if the driver fails to react.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Starting and driving (section 5)" of your Owner's Manual.

---

## AUTOMATIC EMERGENCY BRAKING (AEB) WITH PEDESTRIAN DETECTION SYSTEM (if so equipped)

- The AEB with Pedestrian Detection System can assist the driver when there is a risk of a forward collision with a vehicle ahead in the traveling lane or with a pedestrian.
- The AEB Pedestrian Detection System will function when your vehicle is driven at speeds above approximately 3 mph (5 km/h). For the pedestrian detection function, the AEB Pedestrian Detection System operates at speeds between 6-37 mph (10-60 km/h).
- If there is a risk of a forward collision with a vehicle, an audible tone will sound and the vehicle ahead detection indicator **1** will illuminate. In addition, the system applies partial braking. If the driver does not take action, the AEB Pedestrian Detection System will provide a second set of audible and visual warnings to the driver and then automatically apply harder braking.
- If there is a risk of a forward collision with a pedestrian, an audible tone will sound and the AEB emergency warning indicator **2** will flash. Partial braking will be applied, followed by harder braking if the driver fails to react.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Starting and driving (section 5)" of your Owner's Manual.

## LANE DEPARTURE WARNING (LDW) AND INTELLIGENT LANE INTERVENTION (I-LI) (if so equipped)

- The LDW system can help alert the driver when the vehicle is traveling too close to either the left or the right side of a traveling lane.
- The system will operate when the vehicle is driven at speeds of approximately 37 mph (60 km/h) and above and only when the lane markings are clearly visible on the road.
- When the vehicle approaches either the left or the right side of the traveling lane, the LDW system will vibrate and the LDW light **1** on the vehicle information display will blink to alert the driver.
- The I-LI system can assist the driver in returning the vehicle to the center of the traveling lane by applying individual brake pressure to the left or right wheels for a short period of time.
- The LDW system can be turned on and off through the vehicle information display.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" and the "Starting and driving (section 5)" of your Owner's Manual.

## BLIND SPOT WARNING (BSW) WITH REAR CROSS TRAFFIC ALERT (RCTA) (if so equipped)

- The BSW system helps to alert the driver when another vehicle moves into the vehicle's detection zone.
- An indicator light **1** located on the outside mirrors will illuminate if the radar sensors detect a vehicle in the detection zone.
- The warning systems can be deactivated using the Settings menu. When the system is off, the indicator light **1** on the mirrors and the indicator **2** in the vehicle information display will extinguish.
- The indicator lights **1** will illuminate after the ignition switch is ON and the BSW system is enabled. This indicates that the BSW system is operational.
- The RCTA system helps to alert the driver of an approaching vehicle when the driver is backing out of a parking space. The system operates when the shift lever is in the **R** (Reverse) position and the vehicle speed is less than approximately 5 mph (8 km/h).
- The radar sensors detect an approaching vehicle from up to 66 ft (20 m). The sensors are located on both sides near the rear bumper. The system gives visual and audible warnings if an approaching vehicle is detected.
- The RCTA system can be turned on or off through the Settings menu in the vehicle information display.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" and the "Starting and driving (section 5)" of your Owner's Manual.

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

# NEW SYSTEM FEATURES

## APPROACHING VEHICLE SOUND FOR PEDESTRIANS (VSP) SYSTEM


- The VSP system helps alert pedestrians to the presence of the vehicle when it is being driven at a low-speed.
- When the vehicle starts to move, it produces a sound. The sound stops when the vehicle speed reaches approximately 19 mph (30 km/h) while accelerating.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "EV overview (section EV)" of your Owner's Manual.

## HEATED SEATS (if so equipped)

- The front seats can be warmed by built-in heaters.
- The heated switches **1**, located on the center console, can be operated independently of each other.
- The heater is controlled by a thermostat, automatically turning the heater on and off. The indicator light will remain on as long as the switch **1** is on.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.

## SiriusXM TRAVEL LINK AND SiriusXM TRAFFIC (if so equipped)

- Your vehicle's Navigation System is equipped with SiriusXM Travel Link and SiriusXM Traffic capabilities.
- Touch the **i** "Info" key to access SiriusXM Travel Link and SiriusXM Traffic.
- SiriusXM Travel Link provides access to real-time weather information and forecasts, Charging Station Info, movie listings, sport scores and stock quotes.
- SiriusXM Traffic provides information that may help to avoid delays due to traffic incidents. Traffic jams, roadwork, road closures around the current location, etc., are represented graphically on the map by icons depicting the nature of the event. Incidents on the route are automatically displayed as they are approached.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to your NissanConnect® Manual (for Leaf).

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).



## SHIFT CONTROL SYSTEM

This vehicle is equipped with an electric shift control system **1**, providing smooth and easy shift lever operation.

- There are five shift positions for operating the vehicle: **P** (Park), **R** (Reverse), **N** (Neutral), **D** (Drive) and **B** mode.
  - **P** (Park) – Activated by pushing the **P** (Park) switch on the shift lever when the vehicle has come to a complete stop.
  - **D** (Drive) – For normal driving, it is activated by moving the shift lever left and down. The shift lever will then return to the center position.
  - **B** mode – Engages the regenerative braking system more aggressively when decelerating, helping to put energy back into the battery pack. To enter **B** mode, the vehicle must be in **D** (Drive) and then move the shift lever to the **D** (Drive) position again. The shift lever will then return to the center position.
- **ECO** mode – Consumes less power and helps extend vehicle range.
  - While in either **D** (Drive) or **B** mode, **ECO** mode can be activated by pushing the **ECO** switch **2** located in the center console.
  - While in **ECO** mode, there will be a reduced acceleration response.








Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.


For more information, refer to the "**EV overview (section EV)**" and the "**Starting and driving (section 5)**" of your Owner's Manual.

# NEW SYSTEM FEATURES





## APPLE CARPLAY™ (if so equipped)

- The in-vehicle system can be used as a controller for some of the iPhone® functions through Apple CarPlay™.
- If your iPhone is compatible, Apple CarPlay can be used.
  - Select the “ MENU” key **1** on the screen.
  - Select “Apple CarPlay” **2** from the menu.
- To connect your compatible iPhone to the system, you must connect the iPhone cable to the USB port located in the center console.
  - Depending on the setting, the “Startup Information” screen will appear.
  - Touch “Yes” to use Apple CarPlay.
  - The Apple CarPlay top menu screen will appear, and the iPhone functions displayed on the screen can be operated by the in-vehicle system.
  - To return to the “Apple CarPlay” top menu screen after operation, touch the  key **4** on the lower left corner of the “Apple CarPlay” screen.
  - To exit the “Apple CarPlay” screen and display the other screens, press the **MENU** button or one of the other buttons on the control panel and touch the preferred menus.
  - To return to the “Apple CarPlay” screen, touch the  Info key **3** on the Launch Bar and then touch the “Apple CarPlay” key **2**.
- When connected to Apple CarPlay, Siri® operation can also be accessed.
- There are three ways to start a Siri session.
  1. Press and hold the  button on the steering wheel.
  2. Touch and hold the  key **4** at the lower left corner of the “Apple CarPlay” screen.
  3. Say “Hey Siri” (requires appropriate permissions enabled via phone.)



To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

- Press the  button on the steering wheel or touch the  key **4** at the lower left corner of the "Apple CarPlay" screen to end Siri.
- Keep the interior of the vehicle as quiet as possible. Close the windows to eliminate the surrounding noises (traffic noises, vibration sounds, etc.), which may prevent the system from recognizing the voice commands correctly.
- Some Siri functions may not be available during driving.
- For functions that can be used with Siri, please refer to the Apple® website.
- Nissan Phone menu and Nissan Voice Recognition cellular phone commands will not be available when Apple CarPlay is active.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Getting started (section 1)", the "Viewing information (section 6)" and the "Troubleshooting guide (section 10)" of your NissanConnect® Manual (for Leaf).



## ANDROID AUTO™ (if so equipped)







- The in-vehicle system can be used as a controller for some of the Android® functions through Android Auto™.



### INITIAL SETUP

- Download the Android Auto app from the Google Play™ store to your compatible Android phone.
- Launch the app from your Android phone and follow the directions for setting up the application.
- Complete the initial set-up as prompted on your Android phone. Several permissions will need to be given to the app for Android Auto to fully function on your in-vehicle system.

# NEW SYSTEM FEATURES

## USING ANDROID AUTO

- To connect your Android Auto capable cellular phone to the system, you must connect a USB cable to the USB port located below the center console.
  - Depending on the setting, the "Startup Information" screen will appear on the center display.
  - Touch "Yes" to use Android Auto.
  - The Android Auto top menu screen will appear, and the Android functions displayed on the screen can be operated by the in-vehicle system.
- When connected to Android Auto, voice operation can be accessed. There are three ways to start voice operation:
  1. Press and hold the  button on the steering wheel until a beep is heard.
  2. Touch the  key **1** on the upper right corner of the Android Auto screen.
  3. Say "OK Google" (requires appropriate permissions enabled via cellular phone).
- To return to the Android Auto top menu screen after operation, touch the  key **2** on the bottom of the Android Auto screen.
- To exit the Android Auto screen and display the other screens, touch the  MENU" key **5** or touch the  key **3**.
- To return to the Android Auto screen, touch the  Info" key **4** on the Launch Bar and then touch the "Android Auto" key **6**.
- Nissan Phone menu and Nissan Voice Recognition cellular phone commands will not be available when Android Auto is active.
- If you have difficulties with connection or performance, try a different certified USB cable.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Getting started (section 1)", the "Viewing information (section 6)" and the "Troubleshooting guide (section 10)" of your NissanConnect® Manual (for Leaf).

# ESSENTIAL INFORMATION

## COLD WEATHER RANGE AND PARKING IN EXTREMELY COLD WEATHER

### COLD WEATHER RANGE

- Vehicle range is reduced when the heater is used and the battery temperature drops below 77°F (25°C).
- Using the climate control system to heat the cabin when the outside temperature is below 32°F (0°C) uses more electricity (heat pump, if so equipped) and affects vehicle range more than using the heater at temperatures above 32°F (0°C).

### PARKING IN EXTREMELY COLD WEATHER

- Do not store the vehicle in temperatures below -13°F (-25°C) for over seven days. If the outside temperature is -13°F (-25°C) or lower, the Li-ion battery may freeze, and it cannot be charged or provide power to run the vehicle.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "**EV overview (section EV)**" and the "**Starting and driving (section 5)**" of your Owner's Manual.

---

## QUICK CHARGE IN COLD WEATHER (if so equipped)

- It may take more time to charge the Li-ion battery using the quick charger if the vehicle is parked in a cold location (for example, 32°F [0°C]) for a long period of time.
- It may take more time to charge the Li-ion battery using the quick charger if the temperature of the Li-ion battery is high or low.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "**Charging (section CH)**", the "**Instruments and controls (section 2)**", and the "**Starting and driving (section 5)**" of your Owner's Manual.

# ESSENTIAL INFORMATION

## LI-ION BATTERY TEMPERATURE GAUGE AND LI-ION BATTERY GAUGES

### LI-ION BATTERY TEMPERATURE GAUGE

- Quick charging is possible if the battery temperature is not near the red zone **1**.
- If the battery temperature reaches the red zone **1**, quick charging is not allowed and the power limitation mode will be triggered.



### LI-ION BATTERY GAUGES

- The Li-ion Battery Available Charge Gauge **2** displays the approximate available Li-ion battery power remaining to drive the vehicle. Charge the Li-ion battery before the blue bar of the gauge disappears.
- The driving range **3** provides an estimated distance that the vehicle can be driven before recharging is necessary. The driving range is constantly being calculated based on the amount of available Li-ion battery charge and the actual power consumption average.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "EV overview (section EV)", the "Charging (section CH)", and the "Instruments and controls (section 2)" of your Owner's Manual.

## POWER LIMITATION INDICATOR LIGHT

- When the power limitation indicator light illuminates, power provided to the traction motor is reduced.
- This light illuminates in the following conditions:
  - The Li-ion battery available charge is extremely low.
  - The Li-ion battery temperature is very low. (approximately  $-4$  ( $-20^{\circ}\text{C}$ ))
  - The temperature of the Electric Vehicle (EV) system is high (motor, inverter, coolant system, Li-ion battery, etc.).
  - The EV system has a malfunction.
- If the power limitation indicator light is illuminated, follow the instructions provided on the center display.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.

## CHARGE PORT LID/CHARGE CONNECTOR LOCK SYSTEM

- To open the charge port lid, do the following:
  - Push the charge port lid switch **1** on the instrument panel, or
  - Press and hold the charge port lid opener button **2** on the Intelligent Key for more than 1 second.
  - When the charge port lid springs up slightly, place your hand underneath the lid and open it fully.



- To close the charge port lid, slowly move the lid down and lock it securely in place.
- The normal or trickle charge connector can be locked to the normal charge port by selecting the charge connector lock mode in the vehicle information display.
- There are three different modes of the charge connector lock system:



**AUTO** – The charge connector is locked while charging is in progress and unlocked automatically when charging is complete.

**LOCK** – The charge connector will remain locked until UNLOCK mode is selected or until the temporary unlock operation is performed.

**UNLOCK** – When the unlock mode is selected, the charge connector will unlock and remain unlocked.

### TEMPORARY UNLOCK MODE

When the charge connector lock mode is selected **AUTO** or **LOCK** in the vehicle information display, the charge connector lock can be unlocked temporarily with the Intelligent Key or the charge port lid switch **1** on the instrument panel.

- Press the charge port lid opener button **2** on the Intelligent Key for more than 1 second or push the charge port lid switch **1** on the instrument panel.
  - The status indicator light flashes three times.
  - A beep sounds three times.
  - The charge connector lock is unlocked for 30 seconds.
- After 30 seconds, the charge connector lock is locked.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Charging (section CH)", the "Instruments and controls (section 2)", the "Pre-driving checks and adjustments (section 3)" and the "Starting and driving (section 5)" of your Owner's Manual.

# ESSENTIAL INFORMATION


## LI-ION BATTERY CHARGING

Before charging the Li-ion battery, see your Owner's Manual for detailed warnings and cautions when charging your battery.

- There are three methods available to perform the charge operation: normal charge, trickle charge and quick charge (if so equipped).


### NORMAL CHARGE

- Perform a normal charge using the charger installed in your home.
- Normal charging uses SAE J1772 compliant charger connected to a dedicated 220-240 volt circuit.
- To charge your vehicle:
  - Place the power switch in the OFF position.
  - Push the charge port lid switch located on the instrument panel to the left of the steering wheel.
  - Press the charge port tab and open the cap.
  - Connect the charge connector **1** to the charge port **2**. When connected correctly, a beep will sound once.
- To stop charging:
  - Press the button **3** on the charge connector to release the lock and remove the charge connector from the charge port.
  - Close the charge port cap and the charge port lid.



### TRICKLE CHARGE

- Perform a trickle charge by connecting the Electric Vehicle Supply Equipment (EVSE) (if so equipped) or a SAE J1772 compliant cord set to connect the vehicle to a dedicated AC 110-120 volt, 15A dedicated outlet.
- To charge your vehicle:
  - Place the power switch in the OFF position.
  - Open the charge port lid.
  - Connect the EVSE plug **4** to the 110-120 volt, 15A dedicated electrical outlet. The EVSE control box's green indicator light **5** will illuminate when connected properly.
  - Open the charge port cap.
  - Remove the safety cap from the charge connector.





- Connect the charge connector **6** to the charge port **2**. A beep will sound once.
- You can pass a rope through the hole on the control box in order to hang it up while the Li-ion battery is charging **7**.



- To stop charging:
  - Press the button **3** on the charge connector to release the lock and remove the charge connector from the charge port.
  - Close the charge port cap and the charge port lid.
  - Remove the EVSE plug from the power outlet, attach the safety cap to the charge connector and store it in the case.

#### QUICK CHARGE (if so equipped)

- Perform a quick charge by connecting the charge connector at a public charging station to charge the battery in a short period of time.
- Quick charging is possible if the battery temperature is not near the red zone.

- To charge your vehicle:

- Place the power switch in the OFF position.
- Open the charge port lid and the charge port cap **8**.
- Align the groove of the charge connector with the groove of the charge port then insert the charge connector.



- Grasp the lock lever and lock the charge connector.
- Follow the instructions on the quick charge equipment to start charging. When the equipment is properly installed and ready to charge, a beep sounds twice and the charging status indicator light will change.

- To stop charging:

- The charge connector can be disconnected from the vehicle when the charging is stopped.
- Unlock the charge connector and remove it from the vehicle.
- After closing the charge port cap, close the charge port lid.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "EV overview (section EV)", the "Charging (section CH)" and the "Technical and consumer information (section 9)" of your Owner's Manual.

# ESSENTIAL INFORMATION

## TIRE PRESSURE MONITORING SYSTEM (TPMS) WITH EASY-FILL TIRE ALERT

- A **Tire Pressure Low - Add Air** warning message will appear in the vehicle information display **1** and the low tire pressure warning light **2** will illuminate when one or more tires are low in pressure and air is needed.
- When adding air to an under-inflated tire, the TPMS with Easy-Fill Tire Alert system provides visual and audible signals to help you inflate the tire to the recommended COLD tire pressure.
- To use the Easy-Fill Tire Alert system:
  1. Apply the parking brake and push the **P** (Park) switch on the shift lever.
  2. Place the power switch in the ON position. Do not place the power switch in the READY to drive mode.
  3. Add air to the under-inflated tire, and within a few seconds, the hazard warning lights will flash.
  4. When the designated tire pressure is reached, the horn will beep once and the hazard warning lights will stop flashing.
  5. Repeat this procedure for any additional under-inflated tires.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 mph (25 km/h) and the warning message and warning light will extinguish.
- When the low tire pressure warning light **2** flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked. It is recommended that you visit a Nissan dealer for this service.
- Tire pressure rises and falls depending on the heat caused by the vehicle's operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light **2** to illuminate. If the warning light illuminates, check the tire pressure in your tires.
- The Tire and Loading Information label contains valuable information. Please refer to the "Technical and consumer information (section 9)" of your Owner's Manual for the location of the Tire and Loading Information label.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)", the "Starting and driving (section 5)" and the "Maintenance and do-it-yourself (section 8)" of your Owner's Manual.

## CLOCK SET/ADJUSTMENT

FM/AM/SAT RADIO WITH COMPACT DISC (CD) PLAYER (if so equipped)

1. Press the **ENTER/SETTING** button **1** to show the "Settings" screen on the display.
2. Turn the **TUNE/SCROLL** knob **2** to highlight "Clock Adjust".
3. Press the **ENTER/SETTING** button **1** to highlight the hours or minutes and then use the **TUNE/SCROLL** knob **2** to adjust the value.
4. Press the **ENTER/SETTING** button **1** again to set the value.
5. Press the **BACK** button **3** to return to the previous screen.



NAVIGATION DISPLAY (if so equipped)

1. Press the **MENU** button on the control panel.
2. Touch the "Settings" key on the Launch Bar.
3. Touch the "Clock" key.

■ The following settings can be adjusted:

- **On-screen Clock:** The clock in the upper right corner of the display can be turned ON or OFF.
- **Clock Format (24h):** The clock can be set to 12 hours or 24 hours.
- **Offset (hour):** The time can be adjusted by increasing or decreasing per hour.
- **Offset (min):** The time can be adjusted by increasing or decreasing per minute.
- **Daylight Savings Time:** The application of Daylight Savings Time can be turned ON or OFF.
- **Time Zone:** Adjust the time zone. Choose a time zone from the available list.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual and the "Getting started (section 1)" of your NissanConnect® Manual (for Leaf).

# FIRST DRIVE FEATURES

## NISSAN INTELLIGENT KEY® SYSTEM

The Nissan Intelligent Key® System allows you to lock or unlock the vehicle, open the rear hatch and start your vehicle. It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).



- To lock the vehicle, push either door handle request switch **1** or the rear hatch request switch **2** once or press the **i** button **3** on the key fob.



- To unlock the vehicle, perform one of the following procedures:

- Push any request switch once; the corresponding door will unlock. Push the request switch again within 60 seconds; all other doors will unlock, or
- Press the **i** button **4** on the key fob to unlock the driver's side door. Press the **i** button **4** again within 60 seconds; all other doors will unlock.



- To open the charge port lid, press and hold the charge port lid opener button **5** for more than 1 second.



- The Intelligent Key can also be used to activate the panic alarm by pressing and holding the **panic** button **6** for more than 1 second. Once activated, the panic alarm and headlights will stay on for a period of time.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.

## OUTSIDE MIRROR CONTROL SWITCH

- To select the right or left side mirror, turn the control switch **1** right or left.
- To adjust the mirror angle, move the control switch **1** up, down, right or left.
- To prevent accidentally moving the mirror, turn and set the switch to the center (neutral) position.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.

## FRONT POWER SEAT ADJUSTMENTS (if so equipped for driver's seat)

- To slide the seat forward or backward, push the switch **1** forward or backward.
- To recline the seatback, push the switch **2** forward or backward.



### SEAT LIFTER

- To raise or lower the front portion or height of the seat, push the front or back end of the switch **1** up or down.



### POWER LUMBAR SUPPORT

- To adjust the seat lumbar support, push the front or back end of the switch **3**.



### FOLDING THE REAR SEATBACKS DOWN

- Secure the seat belt on the seat belt hooks **4** located on the side wall.
- To fold the seatback down, pull the release knob **5**.
- To return the seatback to the seating position, lift up each seatback and push it to the upright position until it is latched. Then return the seat belt to its original position.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Safety - Seats, seat belts and supplemental restraint system (section 1)" of your Owner's Manual.

## REAR HATCH RELEASE

To open the rear hatch, unlock it and push the rear hatch opener switch **1**. Pull the rear hatch up to open. The rear hatch can be unlocked by:

- Pressing the **1** button **2** on the Nissan Intelligent Key® twice.
- Pushing the rear hatch request switch **3** while carrying the Intelligent Key with you (that is, in your purse or pocket).
- Pushing the door handle request switch twice.
- Pushing the power door lock switch to the **1** position.



The rear hatch does not lock when closed. To lock the rear hatch, use the request switch, power door lock or key fob.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.


For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.



# FIRST DRIVE FEATURES

## POWER METER

- The power meter **1** displays the traction motor power consumption and the regenerative brake power applied to the Li-ion battery.
- The white segment moves to the right when power is provided to the traction motor.
- The white segment moves to the left when power is generated and provided to the Li-ion battery by the regenerative brake system.
- The illuminated segments on the display are narrowed if the power provided to the motor is limited or if regenerative braking is limited.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.

## ELECTRIC VEHICLE (EV) SYSTEM WARNING LIGHT

- The warning light will illuminate if there is a malfunction in the following systems:
  - Traction motor and inverter system
  - Charge port or on-board charger
  - Li-ion battery system
  - Cooling system
  - Shift control system
  - Emergency shut-off system
- If the warning light illuminates, it is recommended that you visit a NISSAN certified LEAF dealer.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.

## STARTING/STOPPING THE ELECTRIC VEHICLE (EV) SYSTEM

It is important to make sure the Nissan Intelligent Key® is with you (that is, in your pocket or purse).

- Confirm the parking brake is applied and push the **P** (Park) switch on the shift lever to place it in the **P** (Park) position.
- Depress the brake pedal.
- Push the power switch to start the EV system.
- Check that the READY to drive indicator light **1** illuminates and the start-up sound is audible.



To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

- Check the Li-ion battery level and the estimated driving range shown on the meter.

#### TURNING THE EV SYSTEM OFF

- Push the **P** (Park) switch on the shift lever to place it in the **P** (Park) position.
- Apply the parking brake.
- Push the power switch to the OFF position.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Starting and driving (section 5)" of your Owner's Manual.

## HEADLIGHT CONTROL SWITCH

### HEADLIGHT CONTROL

- Turn the headlight control switch to the  $\equiv \text{D} \text{E}$  position **1** to turn on the front parking, side marker, tail, license plate and instrument panel lights. Turn the switch to the  $\equiv \text{D}$  position **2** to turn on the headlights.



### AUTOLIGHT SYSTEM

- The autolight system will automatically turn the headlights on when it is dark and off when it is light. The system will keep the headlights on for a period of time after you turn the ignition off and all doors are closed.
- To activate the autolight system, turn the headlight control switch to the **AUTO** position **3** then turn the power switch to ON. To deactivate the autolight system, turn the headlight control switch to the **OFF** position,  $\equiv \text{D} \text{E}$  position **1** or  $\equiv \text{D}$  position **2**.

### HIGH BEAM SELECT

- With the headlights turned to the  $\equiv \text{D}$  position **2** or the autolight system switched to the **AUTO** position **3**, push the headlight control switch forward **4** to select the high beam function. The blue indicator light will illuminate in the instrument panel. Pull the headlight switch back to the original position to select the low beam. The blue indicator light will extinguish.
- Pull and release the headlight control switch **5** to flash the headlight high beams on and off.



# FIRST DRIVE FEATURES

## FOG LIGHT SWITCH (if so equipped)

In order to operate the fog lights, you must have your headlights on with the low beams selected.

- Turn the switch (inside collar) to the **ON** position **6** to turn the fog lights on.
- Turn the switch (inside collar) to the **OFF** position to turn the fog lights off.



## LANE CHANGE SIGNAL

- Move the lever up or down until the turn signal begins to flash but the lever does not latch to signal a lane change. Hold the lever until the lane change is completed.
- Move the lever up or down until the turn signal begins to flash but the lever does not latch and release the lever. The turn signal will automatically flash three times.

Choose the appropriate method to signal a lane change based on road and traffic conditions.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.

## WIPER AND WASHER SWITCH


- Move the lever to one of the following positions to operate the windshield wipers:

- 1** Mist (**MIST**) - This is a one-sweep operation of the front wipers.
- 2** Intermittent (**INT**) - Front wipers operate intermittently by moving the lever down to the **INT** position and then rotating the control ring **3** to increase or decrease **INT** wiper speed. Also, the intermittent operation speed varies in accordance to the vehicle speed.

- 4** Low (**LO**) - Front wipers operate at a continuous low-speed.

- 5** High (**HI**) - Front wipers operate at a continuous high-speed.

- 6** Front washer - Pull the lever toward you to activate the front washer. The front wipers will operate several times.



## DRIP WIPE

- Once the wiper spray cycle is finished, there will be a short delay. Then the wipers will sweep one more time to clear off any remaining drips from the windshield.



## REAR WIPER AND WASHER SWITCH

- 7** Intermittent (**INT**) – Rear wiper operates intermittently.
- 8** Low (**ON**) – Rear wiper operates at a continuous low-speed.
- 9** Rear washer – Push the lever forward to activate the rear washer. The rear wiper will operate several times.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual.



## HEATER AND AIR CONDITIONER (automatic)

### 1 ON-OFF BUTTON

- Press the **ON-OFF** button to turn the climate control system on or off.

### 2 AUTO BUTTON

- The automatic mode may be used year-round. Press the **AUTO** button, and the system will automatically control the inside temperature (automatic cooling and/or dehumidified heating), air flow distribution and fan speed.

### 3 TEMPERATURE CONTROL BUTTON

- Press the temperature control button up ▲ for warmer air or down ▼ for cooler air.

### 4 FAN SPEED CONTROL BUTTON

- Press the fan speed control button to manually adjust the fan speed up + or down -.

### 5 MODE BUTTON

- Press the **MODE** button to cycle through the following air flow outlets:

- ▲ Air flows from the center and side vents.
- ▲ Air flows from the center, side and foot vents.
- ▲ Air flows mainly from the foot vents.
- ▲ Air flows from the front defroster and foot vents.
- ▲ Air flows from the front defroster vents.

### 6 HEAT BUTTON

- Press the **HEAT** button to manually turn the heater on and off.


To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

# FIRST DRIVE FEATURES





## 7 A/C BUTTON

- Press the **A/C** button to manually turn the A/C on or off.


## 8 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

- Press the  front defroster button to turn the system on. Both the air conditioner and heater will automatically turn on when the front defroster mode is selected. The driving range will be reduced when using this setting.
- Set the temperature control buttons **3** and the fan speed control buttons **4** to their maximum settings.

## 9 INTAKE AIR CONTROL BUTTON

- For air recirculation, press the  intake air control button to recirculate air inside the vehicle. The indicator light on the button will illuminate. This system is used to avoid certain outside odors and to help adjust the inside vehicle temperature more effectively.
- For outside air recirculation, press the  intake air control button again to turn air recirculation off. This allows outside air to be drawn into the passenger compartment to prevent fogging in the front defroster, floor vent or front defroster/floor vent mode.
- The air recirculation mode cannot be activated when the climate control system is in the front defroster mode  or the front defroster and foot vent mode .

## 10 REAR WINDOW AND OUTSIDE MIRROR (if so equipped) DEFROSTER SWITCH

- Push the  rear window and outside mirror (if so equipped) defroster switch to turn the system on or off.
- The rear window defroster automatically turns off after approximately 15 minutes.

## 11 CLIMATE CONTROL TIMER INDICATOR

- The climate control timer indicator light will illuminate when the timer has been set to operate. The climate control timer may be set to a specific date and time.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual.



## FM/AM/SiriusXM® SATELLITE RADIO WITH CD PLAYER (if so equipped)

Touch the “🎵 Audio” key on the Launch Bar to display the current audio source. Touch the “🎵 Audio” key a second time to access the source selection screen.

- 1 🔌 (ON-OFF) BUTTON/VOL (volume) CONTROL KNOB**
  - Press the 🔌 (on-off) button to turn the audio system on or off.
  - Turn the **VOL** (volume) control knob right or left to increase or decrease the volume.
- 2 🎵 AUDIO KEY**
  - Touch the “🎵 Audio” key on the Launch Bar to bring up the current source’s control screen.
- 3 ⏮ / ⏭ (SEEK and CAT/TRACK) BUTTONS**
  - Press the ⏮ button or the ⏭ button to seek up or down to the next receivable station.
  - For satellite radio to switch to the first channel of the previous or next category, press the ⏮ button or the ⏭ button.
  - To change tracks on a CD, press the ⏮ button or the ⏭ button.
  - To rewind or fast forward a track on a CD, press and hold the ⏮ button or the ⏭ button.
- 4 🔊 SOUND BUTTON/TUNE-SCROLL KNOB**
  - Press the **SOUND** button to cycle through the audio settings individually and use the **TUNE-SCROLL** knob to adjust the current setting.
  - Touch the ⚙️ Settings” key on the Launch Bar and then touch the “Sound” key to view all audio settings.
  - To manually tune the radio, turn the **TUNE-SCROLL** knob left or right.

# FIRST DRIVE FEATURES

## 5 AUDIO (SOURCE) BUTTON

- Pressing this button will give access to the AM, FM, SXM, CD, USB/iPod®, Bluetooth® Audio or AUX audio source.
- Twelve memory stations can be set for the FM band, six for the AM band and 18 for satellite radio. These appear at the bottom of the screen when one of these sources is selected.
- To store a station in a preset, you must first select a radio band by touching the "AM" key **6**, "FM" key **7** or "SXM" key **8** then tune to the desired AM, FM or satellite radio station. Next, press and hold the desired station preset key until you hear a beep. The channel indicator will then display, and the sound will resume. Programming is now complete.
- To retrieve a previously set station, select the radio band where the preset was stored then press the corresponding station select key.

## 6 AM KEY / 7 FM KEY

- Touch the "AM" or "FM" key to view the station list or turn HD mode on or off.
- Tag favorite songs to save to an iPod.
  - Apple® website: If you are listening to a radio station that supports iTunes® Tagging, you can tag a song you hear so you can preview and purchase it later on the iTunes Store. Songs that can be tagged are marked with a tag icon next to the song title or on the "Now Playing" screen.

## 8 SXM KEY

- Touch the "SXM" key to bring up the categories, favorites and replay options.

## 9 CD KEY

- Touch the "CD" key to view the track list.

## 10 AUX KEY

- A cable with 1/8 in (3.5 mm) stereo mini plugs is required for audio playback.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the **"Audio system (section 3)"** of your NissanConnect® Manual (for Leaf).

## USB (Universal Serial Bus) CONNECTION PORT/AUX JACK AND IPOD® INTERFACE

- The USB port/AUX jack **1** is located beneath the climate controls.
- When a compatible USB memory device, iPod® or auxiliary device is plugged into the USB port or AUX jack **1**, compatible audio files stored on the device can be played through the vehicle's audio system.
- Touch the "USB/iPod" key to view the folder list and track listing, playlist, album artwork, album name, artist and songs.





For a full list of compatible devices, refer to your NissanConnect® Manual (for Leaf).

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual and your NissanConnect® Manual (for Leaf).

## CRUISE CONTROL (if so equipped)

- The cruise control system enables you to set a constant cruising speed once the vehicle has reached 25 mph (40 km/h).
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.
- To activate the cruise control, push the cruise control switch **1** on the steering wheel. The  indicator in the instrument panel will illuminate.
- To set a cruising speed, accelerate the vehicle to the desired speed, push the **SET -** switch **2** on the steering wheel and release. Take your foot off the accelerator pedal. Your vehicle will maintain the set speed.
- To reset at a faster cruising speed, push and hold the **RES +** switch **3**. When the vehicle attains the desired speed, release the switch.
- To reset at a slower cruising speed, push and hold the **SET -** switch **2**. Release the switch when the vehicle slows to the desired speed.
- To cancel the preset speed, push the **CANCEL** switch **4**.
- To turn off cruise control, push the cruise control switch **1**. The  indicator in the vehicle information display will extinguish.




Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.




For more information, refer to the "Starting and driving (section 5)" of your Owner's Manual.

# FIRST DRIVE FEATURES

## INTELLIGENT CRUISE CONTROL (ICC) (if so equipped) (for vehicles without ProPILOT Assist)

### VEHICLE-TO-VEHICLE DISTANCE CONTROL MODE

- To set Vehicle-To-Vehicle Distance Control mode, push the ICC Switch **1** on the steering wheel. The ICC system ON indicator **2** will illuminate.
- Accelerate to the desired speed.
- Push down on the **SET-** switch **3** on the steering wheel and release it. ICC will be set to the desired speed.
- Push the  distance switch **4** on the steering wheel repeatedly to change the set distance between long, middle and short.
- When a vehicle is not detected ahead of you in the lane, the set distance and set vehicle speed indicator will illuminate **5** in set mode.
- When a vehicle is detected ahead of you in the lane, the vehicle ahead detection, set distance and set vehicle speed indicator will illuminate **6** in set mode.
- To reset at a faster cruising speed, push and hold the **RES+** switch **7** on the steering wheel. When the vehicle attains the desired speed, release the switch.
- To reset at a slower cruising speed, push and hold the **SET-** switch **3** on the steering wheel. Release the switch when the vehicle slows to the desired speed.
- To cancel the preset speed, push the **CANCEL** switch **8** on the steering wheel or tap the brake pedal. The set vehicle speed indicator **5** will extinguish.
- To turn off ICC, push the ICC switch **1** on the steering wheel. The ICC system ON indicator **2** in the instrument panel will extinguish.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Starting and driving (section 5)" of your Owner's Manual.

# SYSTEM GUIDE

## VEHICLE INFORMATION DISPLAY

The vehicle information display **1** displays items such as:

- Battery information
- Audio
- Navigation
- Energy economy
- Safety Shield
- Average vehicle speed
- Driving distance
- Driving time
- Cruise control information
- Intelligent Key® information
- Indicators and warnings
- Settings



### USING THE VEHICLE INFORMATION DISPLAY

The vehicle information display can be changed or selected using the **OK** switch **2** and the **↕** or **◀▶** switches **3** located on the steering wheel.

- Push the **↕** or **◀▶** switches **3** on the steering wheel to navigate the vehicle information display.
- Push the **OK** switch **2** on the steering wheel to change or select an item.
- Push the **↶** switch **4** on the steering wheel to go back to the previous menu.

### ODOMETER/TWIN TRIP A & B

The odometer and twin trip odometer **5** are displayed on the vehicle information display when the power switch is in the ON or READY to drive position.



1. Push the **TRIP RESET** switch **6** to change the display between Odometer > TRIP A > TRIP B.
2. Push the **TRIP RESET** switch **6** for approximately 1 second to reset the current displayed trip odometer to zero.



### SETTINGS

The setting mode allows you to change the information displayed in the vehicle information display:

- VDC Setting
- Driver Assistance
- Customize Display
- Vehicle Settings
- EV Settings
- TPMS Settings
- Maintenance
- Clock
- Unit /Language
- Factory Reset

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.





For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.

# SYSTEM GUIDE

## BLUETOOTH® HANDS-FREE PHONE SYSTEM\*

- A cellular telephone should not be used while driving so full attention may be given to vehicle operation.
- For information regarding connecting your cellular phone, refer to the appropriate "Bluetooth® System" section within this guide.

### SYSTEM OPERATING TIPS

- Press the  or  button on the steering wheel to interrupt the voice prompts at any time and speak a command after the tone.
- The "Help" command can be used to hear a list of available commands at any time.
- Reduce background noise as much as possible by closing windows and pointing heater and air conditioner vents away from the ceiling.
- Speak naturally without long pauses and without raising your voice.
- If you experience difficulty with the Nissan Voice Recognition System recognizing a contact name, please try saying both the first and last name of the contact as this improves recognition accuracy.
- To cancel a Voice Recognition session, simply wait 5 seconds, say "Cancel" or "Quit" or press and hold the  or  button on the steering wheel for 5 seconds.
- For more detailed information and instructions, see your cellular phone's Owner's Manual and visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).



\* Some jurisdictions prohibit the use of cellular telephones while driving.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual and the "Hands-Free Phone (section 7)" of your NissanConnect® Manual (for Leaf) or please visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).

## BLUETOOTH® SYSTEM WITHOUT NAVIGATION\* (if so equipped)

### CONNECTING PROCEDURE

1. Press the **ENTER/SETTING** button.
2. Press the **ENTER/SETTING** button again to select "Bluetooth".
3. Use the **TUNE/SCROLL** knob to select "Add Phone." This same screen can be accessed to remove, replace or select a different Bluetooth® device.






4. The system acknowledges the command and asks you to initiate connecting from the cellular phone handset.

- The connecting procedure of the cellular phone varies according to each cellular phone model. For additional information, refer to the cellular phone's Owner's Manual for details. You can also visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth) for instructions on connecting Nissan-recommended cellular phones.
- When prompted, confirm the PIN on the display with the PIN shown on the handset. If your device does not support Secure Simple Pairing and requests you to input a PIN, enter "1234" from the handset.



#### PHONEBOOK REGISTRATION

- When the cellular phone is connected to the in-vehicle module, the data stored in the cellular phone, such as phonebook, outgoing call logs, incoming call logs and missed call logs, is automatically transferred and registered to the system.
- The availability of this function depends on each cellular phone. The copying procedure also varies according to each cellular phone. See your cellular phone's Owner's Manual for more information.
- Up to 1,000 entries per registered cellular phone can be stored in the phonebook.

#### MAKING A CALL

1. Press the  button on the steering wheel. The system will announce the available commands; afterward, a tone will sound.
2. Say: "Call". The system acknowledges the command and announces the next set of available commands.
3. Say the registered person's name. The system acknowledges the command and announces the next set of available commands.
4. Say: "Yes". The system acknowledges the command and makes the call.

#### RECEIVING/ENDING A CALL

- To accept the call, press the  button on the steering wheel.
- To reject the call, press the  button on the steering wheel.
- To hang up, press the  button on the steering wheel.

\*Some jurisdictions prohibit the use of cellular telephones while driving.



Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.


For more information, refer to the "**Monitor, climate, audio, phone and voice recognition systems (section 4)**" of your Owner's Manual or please visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).

# SYSTEM GUIDE

## BLUETOOTH® SYSTEM WITH NAVIGATION\* (if so equipped)

### CONNECTING PROCEDURE

- The vehicle must be stationary when connecting the cellular phone.
- 1. Press the  or  button on the steering wheel and touch the "Connect Phone" key on the center display.



- 2. Initiate connecting from the cellular phone.
  - The connecting procedure varies according to each cellular phone model. For detailed connecting instructions and a list of compatible cellular phones, please visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).
  - When prompted, confirm the PIN on the display with the PIN shown on the handset. If your device does not support Secure Simple Pairing and requests you to input a PIN, enter "1234" from the handset.




- Some cellular phones may require you to accept certain permissions in order to enable features on your Bluetooth® system. During the Bluetooth® pairing process, please check your cellular phone's display for a pop-up with the request to grant phonebook access.



- Granting phonebook access permission will allow your contacts to be downloaded to the vehicle's Bluetooth® system. A pop-up may display on your cellular phone stating that the Bluetooth® system would like to access your contacts and call history. Please select "Allow" or "Yes" to grant this permission.





- If your cellular phone presents the option to not show the message again, please make sure that this item is checked. Doing so will ensure that any changes to your phonebook will be synced with the Bluetooth® system automatically.

- Some cellular phones may incorrectly state that the connection pairing was unsuccessful. Please verify that the touch-screen displays that the connection is successful, or touch  Settings > "Bluetooth" > "Select BT Device" > "Phone" and confirm that your cellular phone is listed.

- 3. When connecting is complete, the screen will return to the "Phone" menu.

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).



## PHONEBOOK SETUP

- Press the **MENU** button on the control panel.
- Touch the "Settings" key on the Launch Bar and touch the "Phone" key. Next touch the "Phonebook" key on the "Phone" menu screen.
- Depending on your cellular phone, the system may automatically download your cellular phone's entire phonebook to the vehicle's Bluetooth® system. During the Bluetooth® pairing process, please check your cellular phone for any requests to download your phonebook or contacts to the vehicle system. If your cellular phone requests permission to download your contacts, please select "Allow" or "Yes". For additional information, refer to "Connecting Procedure" in this section.
- The "Quick Dial" phonebook can also be set for up to twenty entries that can be used with your cellular phone.
  1. Press the  or  button on the steering wheel and touch the "Quick Dial" key.
  2. Touch the "Add New" key at the top of the display. There are different methods to input a phone number. Select one of the following options:
    - **Copy from Call History** to save a number from the Outgoing, Incoming or Missed Calls lists.
    - **Copy from the Phonebook** to save a number that has been downloaded from your handset to the vehicle.
    - **Enter Number by Keypad** to input the number and name manually.





## MAKING A CALL


To make a call, follow this procedure:

1. Press the  or  button on the steering wheel. The Phone menu will appear on the control panel display.
2. Touch the "Quick Dial", "Phonebook", "Call History" or "Dial Number" key.
3. Touch the desired entry from the list.
4. Touch the phone number to start dialing.






## RECEIVING/ENDING A CALL

- To accept the call, press the  or  button on the steering wheel or touch the "Answer" key on the display.



# SYSTEM GUIDE

- To hang up, press the  or  button on the steering wheel or touch the "Hang up" key on the display.
- To reject the call, touch the "Decline" key on the display.





\*Some jurisdictions prohibit the use of cellular telephones while driving.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Getting started (section 1)", "Audio (section 4)", "Hands-Free Phone (section 7)", "Voice recognition (section 8)" and the "Troubleshooting guide (section 10)" of your NissanConnect® Manual (for Leaf) or please visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).

## HANDS-FREE TEXT MESSAGING ASSISTANT\*

- This text messaging feature allows for sending and receiving text messages through the vehicle's interface.
- Using predefined or custom messages, send a text to an entry stored in your Bluetooth® Hands-free Phone System.
- Once enabled, the date, sender and delivery time are shown on the control panel display when the vehicle speed is less than 5 mph (8 km/h).
- Text messages have the option of being read aloud at all speeds.
- Once the vehicle is in motion, text messages can only be replied to using the Voice Recognition  or  button on the steering wheel.
- Text messages can be created manually when the vehicle is not in motion.
- Custom text messages must be created in advance.
- Many cellular phones may require special permission to enable text messaging. Check the cellular phone's screen during Bluetooth® pairing. For some cellular phones, you may need to enable "Notifications" in the cellular phone's Bluetooth® menu for text messages to appear on the touch-screen display. For more detailed information and instructions, refer to your cellular phone's Owner's Manual.
- Text message integration requires that the cellular phone support Message Access Profile (MAP) for both receiving and sending text messages. Some cellular phones may not support all text messaging features. Please see [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth) for compatibility information as well as your device's Owner's Manual.



\*Laws in some jurisdictions may restrict the use of "Text-to-Speech". Some of the applications and features, such as social networking and texting, may also be restricted. Check local regulations for any requirements before using these features.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the your NissanConnect® Manual (for Leaf).

## BLUETOOTH® STREAMING AUDIO\*

- If you have a compatible Bluetooth® device with streaming audio (A2DP profile), you can set up the wireless connection between your Bluetooth® device and your vehicle's audio system. This connection allows you to listen to audio from the Bluetooth® device using your vehicle's speakers.
- A cellular telephone should not be used while driving so full attention may be given to vehicle operation.

### CONNECTING PROCEDURE WITH NAVIGATION SYSTEM (if so equipped)

1. Touch the "🎵 Audio" key and touch the "Bluetooth Audio" key.
2. A prompt to connect your device will display.
  - If the device is already paired:
    - a. Touch the "Select Devices" key to play from an already paired device.
    - b. Select the desired device and touch the "Connect" key **1**.
    - c. The last played audio will start playing once the device is connected.
  - If the device needs to be connected:
    - a. Touch the "⚙️ Settings" key.
    - b. Touch the "Bluetooth" key.
    - c. Touch the "Connect Device" key.



- Touch the "BT Menu" key to view track listing, artist, songs or albums.
- Touch the "BT Settings" key to change which device is playing audio.

### CONNECTING PROCEDURE WITHOUT NAVIGATION SYSTEM (if so equipped)

To connect your Bluetooth® audio device to the vehicle, follow the procedure below:

1. Press the **ENTER/SETTING** button.
  2. Press the **ENTER/SETTING** button again to select "Bluetooth".
  3. Use the **TUNE/SCROLL** knob to select "Add Phone." This same screen can be accessed to remove, replace or select a different Bluetooth® device.
  4. The system acknowledges the command and asks you to initiate connecting from the cellular phone handset. The connecting procedure of the cellular phone varies according to each cellular phone model. For additional information, refer to the cellular phone's Owner's Manual for details. You can also visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth) for instructions on connecting Nissan-recommended cellular phones.
- To switch to the Bluetooth® audio mode, press the **MEDIA** button repeatedly until the Bluetooth® audio mode is displayed on the screen.

\*Some jurisdictions prohibit the use of cellular telephones while driving.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Monitor, climate, audio, phone and voice recognition systems (section 4)" of your Owner's Manual and the "Getting started (section 1)", "Audio (section 4)", "Voice recognition (section 8)" and the "Troubleshooting guide (section 10)" of your NissanConnect® Manual (for Leaf) or please visit [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth).

To view detailed instructional videos regarding these and other features, please go to [www.nissanownersinfo.mobi](http://www.nissanownersinfo.mobi).

# SYSTEM GUIDE



## NAVIGATION SYSTEM (if so equipped)

- Your Navigation System can calculate a route from your current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle's position. If you have deviated from the original route, it will recalculate the route from your current location.
- To help promote safe driving, some functions cannot be operated or have limited operation when the vehicle speed is above 5 mph (8 km/h). The on-screen text and keys for these restricted functions will be grayed-out or muted and cannot be selected while driving. These functions will become available again when the vehicle speed is reduced to 5 mph (8 km/h). Voice commands may be available for some of the restricted functions. For more information, refer to your NissanConnect® Manual (for Leaf).

- 1 MENU** - Touch to access all available shortcut and widget items in the menu screen.
- 2** Touch-screen
- 3 Map Menu** - Touch to access different options related to either a selected location by touch or one that you have navigated to. Some options include "Save Location", "Nearby POIs", "Map Icons" or "New Destination".
- 4 ▲ Navi** (Navigation) - Touch to access the Navigation function.
- 5 i Info** (Information) - Touch to display the vehicle, traffic (if so equipped) and weather (if so equipped) information.
- 6 ZOOM OUT**, **7 ZOOM IN** - Touch to adjust the map scale. When parked, you can pinch in or out to zoom on the screen.
- 8 Map** - Touch to display the map.
- 9 ⚙ Settings** - Touch to display the system settings.



## SETTING A DESTINATION

You can set a destination with your Navigation System using the touch-screen display or Voice Recognition.

### ■ Touch-screen Display

- Touch the “▲ Navi” key on the Launch Bar.
- When a destination is set, touch the “New Destination” key and then select one of the displayed options for choosing your destination.

### ■ Voice Recognition



- Press the  or  button on the steering wheel, and after the tone, say “Navigation”. From here, the system will give you the options available for setting a destination.

## SETTING A DESTINATION USING POINTS OF INTEREST (POI)

### ■ Touch-screen Display

- Touch the “▲ Navi” key on the Launch Bar, and if a destination is already set, touch the “New Destination” key.
- Touch the “Points of Interest” key and then select one of the displayed options for choosing your destination. To find a specific location, touch the “Spell Name” key and type the desired location’s name using the on-screen keyboard.

### ■ Voice Recognition

- Press the  or  button on the steering wheel, and after the tone, say “Navigation” then say “Points of Interest”. From here, the system will give you the options available for setting a POI.

Please see your Owner’s Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to your NissanConnect® Manual (for Leaf).

# SYSTEM GUIDE



## HOMELINK® UNIVERSAL TRANSCEIVER (if so equipped)

- The HomeLink® Universal Transceiver can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as garage doors, property gates, outdoor and indoor lights or alarm systems.
- To program the HomeLink® Universal Transceiver:
  - Position the handheld transceiver 1-3 in (26-76 mm) away from the HomeLink surface, keeping the HomeLink indicator light in view.
  - Press and hold the desired HomeLink button and the handheld transmitter button simultaneously until the HomeLink indicator light flashes slowly and then rapidly.
  - Both buttons may be released when the indicator light flashes rapidly.
- To verify the programming is complete, press and hold the HomeLink button and observe the indicator light:
  - A solid, continuous light indicates the programming is complete and the HomeLink button will activate your device.
  - A blinking light that turns to a solid, continuous light after 2 seconds indicates additional steps are required to complete the programming.
- An additional person may make the remaining steps easier. To complete the programming process:
  - At the receiver of the device that you are programming to the HomeLink button, press and release the learn or smart button (the name may vary by manufacturer, but it is usually located near where the hanging antenna wire is attached to the unit). You have approximately 30 seconds to initiate the following step.
  - Press and hold the programmed HomeLink button for 2 seconds and release.
- You may have to repeat the previous two steps up to three times to complete the programming process. HomeLink should now activate your device.

Please see your Owner's Manual for important safety information, system limitations, and additional operating and feature information.

For more information, refer to the "Instruments and controls (section 2)" of your Owner's Manual, the HomeLink website at [www.homelink.com](http://www.homelink.com) or call 1-800-355-3515.





# MEMO

# MEMO



## Helpful Resources

Below is a list of helpful resources that can be used to learn more about the vehicle's systems and feature operations.

- Vehicle Owner's Manual
- NissanConnect® Manual (for Leaf)  
(if so equipped)
- Printed Quick Reference Guide (this document)
- [www.NissanUSA.com/bluetooth](http://www.NissanUSA.com/bluetooth)
- [www.NissanUSA.com/connect](http://www.NissanUSA.com/connect)
- [www.youtube.com/user/NissanUSA](http://www.youtube.com/user/NissanUSA)
- Nissan Consumer Affairs: 1-800-647-7261
- Electronic Quick Reference Guide  
(Use Quick Response (QR) code or URL below.)
- Nissan Quick Guide (available in the App Store® or Google Play™ store for download to your smartphone)



To view detailed instructional videos,  
go to [www.nissanownersinfo.mobi/2018/leaf](http://www.nissanownersinfo.mobi/2018/leaf)  
or snap this barcode with an appropriate barcode reader.



This Quick Reference Guide is intended to provide an overview of some of the unique features of your new vehicle. Please see your Owner's Manual for important safety information and system operation limitations. Features and equipment in your vehicle may vary depending on model, trim level, options selected, order, date of production, region or availability. Therefore, you may find information about features or equipment that are not included or installed on your vehicle.

All information, specifications and illustrations in this Quick Reference Guide are those in effect at the time of printing. NISSAN reserves the right to change specifications, performance, design or component suppliers without notice and without obligation. From time to time, NISSAN may update or revise this Quick Reference Guide to provide owners with the most accurate information currently available. Please carefully read and retain, with this Quick Reference Guide, all revision updates sent to you by NISSAN to ensure you have access to accurate and up-to-date information regarding your vehicle. Current versions of vehicle Quick Reference Guides, Owner's Manuals and any updates can also be found in the Owner section of the NISSAN website at <https://owners.nissanusa.com/owners/navigation/manualsGuide>. If you have questions concerning any information in your Owner's Manual, contact NISSAN Consumer Affairs. See the NISSAN CUSTOMER CARE PROGRAM page in the Owner's Manual for contact information.

